BENDIX

OPERATING & INSTALLATION INSTRUCTIONS



TUMBLE DRYER

BTD 01

125994680

⚠ Important Safety Information

It is most important that this instruction book should be retained with the appliance for future reference. Should the appliance be sold or transferred to another owner, or should you move house and leave the appliance, always ensure that the book is supplied with the appliance in order that the new owner can get to know the functioning of the appliance and the relevant warnings.

These warnings have been provided in the interest of safety. You MUST read them carefully before installing or using the appliance.

Installation

- This appliance is heavy. Care should be taken when moving it.
- It is dangerous to alter the specifications or attempt to modify this product in any way.
- Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.
- Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
- If the machine is situated on a carpeted floor, please adjust the feet in order to allow air to circulate freely.
- If the tumble dryer is placed on top of a washing machine, it is compulsory to use the stacking kit (optional accessory).

Child Safety

- This appliance is designed to be operated by adults. Children should not be allowed to tamper with the controls or play with the product.
- Pets and children have been known to climb into tumble dryers. Please check your drum before use.
- Keep all packaging well away for children.

Use

- Do not overload the appliance (see programme chart).
- Clothes which are dripping wet should not be placed in the dryer.
- As some bulky items such as duvets and eiderdowns should be dried in large commercial machines because of their bulk, check with the manufacturer of the item if it is suitable for drying in a domestic machine, even if the dry weight of the item is within the limit advised.
- Do not dry canvas shoes or sports shoes, as they could get stuck between the door and the drum, thus blocking the latter.
- Please make sure that no gas lighters have accidentally been left in pockets of garments to be loaded into appliance.
- **Danger of explosion**: Never tumble dry items that have been in contact with inflammable solvents (petrol, methylated spirits, dry cleaning fluid and the like). As these substance are volatile, they could cause an explosion. Tumble dry only items washed with water.
- In order to avoid danger of fires caused by excessive drying, do not use appliance to dry the following items:
- Cushions, quilts and the like (these items accumulate heat).
- Items containing rubber foam or materials similar to rubber foam.
- Leave the door slightly ajar when the appliance is not being used. This will allow the seal to be preserved.
- Clean fluff filter after using tumble dryer. To prevent fire risks, do not use the appliance if the fluff filter is damaged or without the filter.
- Under no circumstances should you attempt to repair the machine yourself. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Electrolux Service Centre. Always insist on genuine Electrolux spare parts.

Contents

For the User

Important Safety Information 2
- Installation 2
- Child Safety 2
- Use 2

Your New Tumble Dryer 4

Description of the Appliance 4

The Control Panel 5
- Water full indicator light 5
- Mains-on light 5
- Time selector dial/ON-OFF switch 5

Programme Chart 6

Operating Sequence 7
- Load the laundry 7
- Select the drying time 7
- When drying is completed 7

Hints & Tips on Drying 8

Maintenance and Cleaning 9
- External cleaning 9
- Cleaning fluff filter 9
- Cleaning the condenser unit 9
- Emptying the water reservoir 9

Something Not Working 10

Service and Spare Parts 10

Customer Care 10

Guarantee Conditions 11

Electrolux Service Centres 12-13

For the Installer

Installation Instructions 14

Technical Specifications 14
- Positioning 15
- Stacking kit (optional accessory) 15
- Door reversal 16
- Electrical connection 17

Guide to use the Instruction Book

The following symbols will be found in the text to guide you throughout the instructions:

⚠ **Safety instructions**

ⓘ **Hints and tips**

Environmental information

Your New Tumble Dryer

This tumble dryer will give your wash that soft, relaxed feel whatever the weather.

Extremely high quality standards both during development and manufacturing guarantee a long service life for your appliance.

Maximum economy in the operation of your dryer is achieved through very frugal electricity consumption and short drying times.

Energy saving tips

To save energy we recommend that you follow these hints:

- Try to load the maximum capacity of the machine as small loads are **uneconomical**.
- Always load well spun laundry. The higher the spin speed, the lower the electricity consumption and the shorter the drying times.
- Do not over-dry laundry, this avoids creasing and saves energy.
- Clean the filter regularly to avoid excessive drying times and high electricity consumption.
- Ventilate the room well. The room temperature should not exceed +35°C during drying.

In the interest of the environment

- Materials marked with the symbol ♺ are recyclable.
- Check with your local Council or Environmental Health Office to see if there are facilities in your area for re-cycling this appliance.
- When the appliance is to be scrapped, cut off the power supply cable and make the door closing device unusable to prevent young children from being trapped inside.
- Help to keep your country tidy - use authorised disposal sites for your old appliance.

How do we help to protect the environment? We use recycled paper!

Description of the Appliance

1 Worktop
2 Programme Chart
3 Full Tank Indicator Light
4 Mains-On Light
5 Door Opening Button
6 Time Selector Dial-ON/OFF switch
7 Fluff Filter
8 Door Catch
9 Rating Plate
10 Ventilation Grille
11 Condenser Unit
12 Water Reservoir (Tank)
13 Adjustable Feet



The Control Panel


COTTONS - LINENS
2.5 kg Cupboard Dry 55 - 75 min
5 kg Cupboard Dry 85 -110 min
2.5 kg Iron Dry 40 - 60 min
5 kg Iron Dry 65 - 95 min
Refresher 12 min
SYNTHETICS MIXED FABRICS
1 kg Cupboard Dry 30 - 40 min
2,5 kg Cupboard Dry 65 - 75 min
1 kg Iron Dry 25 - 35 min
2,5 kg Iron Dry 45 - 55 min
Refresher 12 min
BTD 01
IMPORTANT: PLEASE READ THE INSTRUCTION BOOK BEFORE USE
FULL TANK
MAINS ON
BENDIX
DOOR OPENING
CONDENSER DRYER with reverse anti-crease action
DRYING TIME
1
2
3
4
5

1 Programme Chart

This will help you to select the correct time for drying.

2 Full Tank Indicator Light

This light illuminates when the water reservoir is full or improperly fitted.
The programme will be interrupted.
Attention: The time selector dial continues to turn towards the "**0**" position, but the drying cycle is stopped, that means that the laundry is not dried.
After having emptied the tank, you have to select the drying programme again for the time required to complete drying.

After this operation, the dryer can remain inactive for 20 seconds before starting the programme and during this period the FULL TANK light remains alight.

3 Mains-On Light

This light indicates operating status. It switches off at the end of the programme.

4 Door Opening Button

Depress this button to open the door.
Should the door be opened while appliance is working, the tumble dryer will stop functioning but the time selector dial continues to turn.

5 Time Selector Dial-On/Off Switch ⏻

Turn the dial clockwise (to the right) to select the time for drying (see Chart page 6). At the same time the machine is switched on and the programme starts.

This dryer has two drying cycles of up to 120 and 80 minutes, giving a high or low heat temperature according to the type of fabric.

When selecting the drying time you should remember that it includes a 12 minute cooling phase (position on the dial).

This phase should not be shortened, stopped or avoided, as this could cause skin burns or damage to the laundry.

Programme Chart

Cottons and linens

Selector dial up to 120 minutes (high temperature section)

Type of laundry:	Degree of drying	Max. amount of laundry	Drying time in minutes for laundry spun at
			1000/1200 rpm
Cotton Towelling Shirts Sheets Hand towels Tablecloths Table napkins	Cupboard dry (wardrobe dry)	5 kg	85-110
		2.5 kg	55-75
	Iron dry (not completely dry; suitable for ironing)	5 kg	65-95
		2.5 kg	40-60

Synthetics

Selector dial up to 80 minutes (low temperature section)

Type of laundry:	Degree of drying	Max. amount of laundry	Drying time in minutes for laundry spun at a minimum speed of 650 rpm
Synthetics or mixed fabrics which do not require ironing.	Cupboard dry	2.5 kg	65-75
		1 kg	30-40
Synthetics or mixed fabrics suitable for ironing.	Iron dry	2.5 kg	45-55
		1 kg	25-35

ATTENTION! Please follow the instructions on labels when drying mixed fabrics.

Never overfill the drum (do not load large quilts, for example).

Drying times vary according to:
- The type of laundry
- The size of the load
- The degree of spinning prior to drying
- The degree of drying required

Refresher

This position on the programme selector dial can be used to freshen the laundry (e.g. to remove a persistent odour of moth-balls).

Load

It is often difficult to estimate the weight of items to be dried. We therefore recommend that you adopt the following guidelines:
- cotton, linen: drum full but not too tightly packed
- synthetics: drum no more than half full

Operating Sequence

Before using your tumble dryer for the first time, we recommend you place a few damp cloths inside the appliance and dry for approximately 20 minutes. There may be dust inside a brand new tumble dryer.

1. Load the laundry

Open the door by pressing the relevant button.
Load the items one at a time, shaking them out loosely and close the door.
Please check the laundry does not get caught between the door and filter.



2. Select the drying time

Turn the selector dial clockwise to the desired time (in the high or low temperature section, according to the fabric).
The mains-on light illuminates and the programme starts.



3. When drying is completed

The machine stops automatically and the mains-on light goes out.

Open the door and take out the laundry.

Clean the filter and empty the tank after every drying programme.
A clean filter ensures correct functioning of the appliance.

Hints & Tips on Drying

Before placing articles of laundry in your tumble dryer, check the care labels to ensure they are recommended for tumble drying.

Care Labels you may find on your laundry

- normal drying (high temperature)
- delicate drying (low temperature)
- do not tumble dry
- may be tumble dried

Do not overload the appliance.

Here is a list of the approximate weight of some common laundry items.

Sheet	700 to 1000 g
Pillowcase	100 to 200 g
Tablecloth	400 to 500 g
Table Napkin	50 to 100 g
Kitchen Towel	70 to 120 g
Linen Hand Towel	100 to 150 g
Hand Towel	150 to 250 g
Bath Towel	700 to 1000 g
Bathrobe	1000 to 1500 g
Shirt	200 to 300 g
Apron	150 to 200 g

- Always load well spun laundry. The higher the spin speed the lower the electricity consumption and the shorter the drying time.
- DO NOT load dripping wet laundry into the dryer. Roll the article in a towel or spin to remove excess water.
- Close poppers and zips and fasten any buttons.
- Sort the laundry. Separate synthetics from cotton/linens, and dry separately.
- Remove the laundry immediately after the programme has finished.
- Use a fabric conditioning sheet to reduce static. We recommend the sheet is pinned to an article of laundry (using a safety pin).
- Mix the load i.e. large and small articles.
- When drying large items such as sheets, we recommend you periodically stop the dryer to redistribute the load.

DO NOT use the tumble dryer to dry the following:

- Articles contaminated with inflammable substances e.g. petrol, cleaning solvents, cooking oil, fats or hair lacquer.
- Woollen and synthetic/wool mixtures unless the item is labelled as suitable for tumble drying.
- Very delicate articles such as silk.
- Very large and bulky items such as duvets or sleeping bags.

Maintenance and Cleaning

*You must **disconnect** the appliance from the electricity supply, before you can carry out any cleaning or maintenance work.*

External cleaning

Use only soap and water and then dry thoroughly. From time to time, apply a little wax furniture cream with a soft cloth.
Important: do not use methylated spirit, diluents or similar products.

Cleaning the filter

The tumble dryer cannot operate efficiently with a clogged filter. The filter collects all the fluff which forms during drying and it is therefore essential to remove and clean this filter after each drying programme before removing the laundry.
Remove the fluff around the filter too.



You should not be alarmed by the amount of fluff which collects on the filter; this is due to normal wearing of the fabrics dried and not to incorrect operation of your machine. Rubbing of the fibres during normal wear and washing forms fluff. If laundry is dried on a line, this fluff simply flies away, whereas inside the tumble dryer it collects together and swells considerably as a result of the drying action.

Cleaning the condenser unit

Clean the air condenser periodically, 3 or 4 times a year depending on how frequently the dryer is used. Pull out the condenser, holding it at the top, and remove all fluff. Clean it with a brush and rinse it under the shower if necessary.





Also clean the outside, removing all fluff.
Clean the rubber seal round the porthole door and the seal of the condenser in the inner door with a damp cloth.

Emptying the water reservoir(tank)

Water extracted from the laundry condenses inside the machine and is collected in a reservoir.
The reservoir must be emptied after each drying cycle to ensure efficient operation when the machine is next used.
If this is not done a safety device trips: pilot light FULL TANK on the control panel comes on and the programme stops, leaving the laundry damp.

The reservoir can be emptied even in the middle of a programme.



The reservoir must be re-inserted correctly.

Important: When emptying the reservoir during the drying cycle, the machine stops drying, but the drying time selector dial will continue to step on.

Handy tip: The condensed water may be used in a steam iron or to top up a battery, etc. In this case it must be filtered (e.g. through a coffee filter).

Something Not Working

Certain problems are due to lack of simple maintenance or oversights, which can be solved easily without calling out an engineer. Before contacting your local Service Centre, please carry out the checks listed below.

IMPORTANT: if you call out an engineer to a fault listed below, or to repair a fault caused by incorrect use or installation, a charge will be made even if the appliance is under guarantee.

Symptom	Possible causes
The tumble dryer does not start	■ The door has not been closed. ■ The plug is not properly inserted in the power socket. ■ There is no current at the socket ■ The main fuse or the fuse in the plug has blown. ■ A drying time has not been selected. ■ The water reservoir is full or not properly inserted (the pilot light FULL TANK is on).
Drying takes too long or laundry is not dry enough.	■ The laundry has not been spun properly. ■ The filter and/or air condenser are clogged up. ■ The water reservoir is full during operation. ■ The room temperature is too high. ■ The selected time or section was not suitable for the laundry ■ There is too much laundry inside the appliance. ■ The dryer is not correctly installed.

If after the above checks, there is still a fault, call your local Electrolux Service Force Centre.

Service & Spare Parts

If you require an engineer or wish to purchase spare parts contact your local Electrolux Service Force Centre by telephoning:

0870 5 929929

Your telephone call will be routed to the Service Centre covering your post code area.
The addresses are detailed in this instruction book on the pages headed Electrolux Service Force Centres, and can also be found in your local telephone directory under “E”.
When you call the Service Force Centre please make sure you give the model and serial number of the appliance.

This information can be found on the rating plate (see picture on page 4) or on the guarantee card.

In-guarantee customers should ensure that the above checks have been made as the engineer will make a charge if the fault is not a mechanical or electrical breakdown. Please note that proof of purchase is required for any in-guarantee service calls.

Customer Care

For general enquiries concerning your Electrolux appliance or for further information on Electrolux products, please contact our Customer Care Department by letter or telephone as follows:

Customer Care Department
Electrolux
55-57 High Street
Slough
Berkshire
SL1 1DZ
Tel 08705 950950*

* calls to this number may be recorded for training purposes.

SERVICE FORCE

To contact your local Service Force Centre telephone 08705 929 929

CHANNEL ISLANDS

GUERNSEY	Guernsey Electricity PO Box 4 Vale, Guernsey Channel Islands GY1 3AD
JERSEY	Jersey Electricity Company Haut De L'orme Rue De Haut De L'orme Trinity Jersey Channel Islands JE3 5FG

SCOTLAND

ABERDEEN	54 Claremont Street Aberdeen AB10 6RA
AUCHTERMUCHTY	33a Burnside Auchtermuchty Fife KY14 7AJ
BLANTYRE	Unit 5 Block 2 Auchenraith Ind. Estate Rosendale Way Blantyre G72 0NJ
DUMFRIES	93 Irish Street Dumfries DG1 2 PQ
DUNOON	7 Hill Street Dunoon Argyll PA23 7AL
EDINBURGH	Unit 12 Dumbryden Ind. Estate 2 Dumbryden Road Edinburgh EH14 2AB
GLASGOW	Unit 4 Wellington Road Bishopriggs Glasgow G64 2SA
INVERNESS	Unit 3BI Smithton Ind. Estate Smithton Inverness IV2 7WL
ISLE OF ARRAN	Arran Domestics The Douglas Centre Brodick Isle of Arran KA27 8AJ
ISLE OF BARRA	J Zerfah 244 Bruernish Isle of Barra Western Islands HS9 5QY
ISLES OF BUTE	Walker Engineering Glenmhor Upper Serpentine Road Rothesay Isle of Bute PA20 9EH
ISLE OF LEWIS	ND Macleod 16 James Street Stornoway Isle of Lewis PA87 2QW
KELSO	2, 6 & 8 Woodmarket Kelso Borders TD5 7AX
ORKNEY	7 King Street Kirkwall Orkney KW15 1JF
PERTH (OWN SALES)	Scottish Hydro Electric Central Warehouse Inveralmond Perth PH1 3AF
SHETLAND (OWN SALES)	3-4 Carlton Place Lerwick Shetland ZE1 0PW
SHETLAND (OWN SALES)	Bolts Shetland 26 North Road Lerwick Shetland ZE1 0PE
WHALSAY (OWN SALES)	Leask Electrical Harisdale Symbister, Whalsay Shetland ZE2 9AA

NORTHERN IRELAND

BELFAST	Owenmore House Kilwee Business Park Dunmurry Belfast BT17 0HD

WALES

CARDIFF	Unit 4 Guardian Industrial Estate Clydesmuir Road Cardiff CF2 2QS
CLYWD	Unit 6-7 Coed Parc Abergele Road Rhuddlan Clwyd LL18 5UG
DYFED	Unit 9 St. Clears Business Park Tenby Road St. Clears Carmarthen SA33 4JW
OSWESTRY	Plas Ffynnon Warehouse Middleton Road Oswestry SY11 2PP

NORTH EAST

GATESHEAD	Unit 356a Dukesway Court Dukesway Gateshead NE11 0BH
GRIMSBY	15 Hainton Avenue Grimsby N. E. Lincs DN32 9AS
HULL	Unit 1 Boulevard Industrial Estate Hull HU3 4AY
LEEDS	64-66 Cross Gates Road Cross Gates Leeds LS15 7YS
NEWTON AYCLIFFE	Unit 23 Northfield Way Aycliffe Industrial Park Newton Aycliffe DL5 6EJ
SHEFFIELD	Pennine House Roman Ridge Road Sheffield S9 1GB

NORTH WEST

BIRKENHEAD	1 Kelvin Park Dock Road Birkenhead CH41 1LT
CARLISLE	Unit 7 James Street Workshops James Street Carlisle Cumbria CA2 5AH
ISLE OF MAN	South Quay Ind. Estate Douglas Isle of Man IM1 5AT
BOLTON	Unit B Central Industrial Estate St Marks Street Bolton BL3 6NR
PRESTON	Unit 250 Dawson Place Bamber Bridge Preston Lancashire PR5 8AL
STOCKPORT	Unit 20 Haigh Park Haigh Avenue Stockport SK4 1QR

SERVICE FORCE

To contact your local Service Centre telephone 08705 929 929

MIDLANDS

BIRMINGHAM	66 Birch Road East Wyrley Trading Estate Witton Birmingham B6 7DB
BOURNE	Pinfold Road Bourne PE10 9HT
BRIDGNORTH	68 St. Mary's Street Bridgnorth Shropshire WV16 4DR
GLOUCESTER	101 Rycroft Street Gloucester GL1 4NB
HEREFORD	Units 3 & 4 Bank Buildings Cattle market Hareford HE4 9HX
HIGHAM FERRERS	30 High Street Higham Ferrers Northants NN10 8PL
ILKESTON	Unit 2 Furnace Road Ilkeston DE7 5EP
LEICESTER	Unit 7 Oaks Industrial Estate Coventry Road Narborough Leicestershire LE9 5GF
LINCOLN	Unit 8 Clifton Street Stone Field Park Lincoln LN5 8LQ
NEWCASTLE UNDER LYME	18-21 Croft Road Brampton Ind. Estate Newcastle under Lyme Staffordshire ST5 0TW
REDDITCH	13 Thornhill Road North Moons Moat Redditch Worcestershire B98 9ND
TAMWORTH	Unit 3 Sterling Park Claymore Tamworth B77 5DQ
WORCESTER	Units 1 & 2 Northbrooks Close Gregorys Mill Ind. Estate Worcester WR3 8BP

LONDON & EAST ANGLIA

BECKENHAM	11a Gardner Ind. Estate Kent House Lane Beckenham Kent BR3 1QZ
CHELMSFORD	Hanbury Road Widford Ind. Estate Chelmsford Essex CM12 3AE
COLINDALE	Unit 14 Capitol Park Capitol Way Colindale London NW9 0EQ
ELTHAM	194 Court Road Mottingham Eltham London SE9 4EW
ENFIELD	284 Alma Road Enfield London EN3 7BB
GRAVESEND	Unit B4 Imperial Business Estate West Mill Gravesend Kent DA11 0DL
IPSWICH	Unit 6C Elton Park Business Centre Hadleigh Road Ipswich IP2 0DD
LETCHWORTH	16-17 Woodside Ind. Park Works Road Letchworth Herts SG6 1LA
LONDON	2 - 4 Royal Lane Yiewsley West Drayton Middlesex UB7 8DL
MAIDENHEAD	Reform Road Maidenhead Berkshire SL6 8BY
MOLESEY	10 Island Farm Avenue West Molesey Surrey KT8 2UZ
NEWBURY	9 Pipers Court Berkshire Drive Thatcham Berkshire RG19 4ER
NORWICH	2b Trafalgar Street Norwich NR1 3HN
SUNBURY	Unit 1a The Summit Hanworth Road Sunbury on Thames TW16 5DB

SOUTH EAST

ASHFORD	Unit 2 Bridge Road Business Centre Bridge Road Ashford Kent TN23 1BB
FLEET	Unit 1 Redfields Ind. Estate Church Crookham Fleet Hampshire GU13 0RD
HAYWARDS HEATH	21-25 Bridge Road Haywards Heath Sussex RH16 1UA
TONBRIDGE	Unit 30 Deacon Trading Estate Morley Road Tonbridge TN9 1RA

SOUTH WEST

BARNSTAPLE	Main Road Fremington Barnstaple North Devon EX31 2NT
BOURNEMOUTH	63-65 Curzon Road Bournemouth Dorset BH1 4PW
BRIDGEWATER	6 Herswell Business Park Salmon Parade Bridgwater Somerset TA6 5PY
BRISTOL	11 Eldon Way Eldonwall Trading Estate Bristol BS4 3QQ
EMSWORTH	266 Main Road Southbourne Emsworth PO10 8JL
ISLE OF WIGHT	Unit 8 Enterprise Court Ryde Business Park Ryde Isle of Wight PO33 1DB
NEWTON ABBOT	Unit 2 Zealley Ind. Estate Kingsteignton Newton Abbot TQ12 3TD
REDRUTH	Unit 7D Pool Ind. Estate Druids Road Redruth Cornwall TR15 3RH

Guarantee Conditions

Standard guarantee conditions

We, Electrolux, undertake that if, within 12 months of the date of the purchase, this Electrolux appliance or any part thereof is proved to be defective by reason only of faulty workmanship or materials, we will, at our option, repair or replace the same FREE OF ANY CHARGE for labour, materials or carriage on condition that:

- The appliance has been correctly installed and used only on the electricity supply stated on the rating plate.
- The appliance has been used for normal domestic purposes only, and in accordance with the manufacturer's instructions.
- The appliance has not been serviced, maintained, repaired, taken apart or tampered with, by any person not authorised by us.

All service work under this guarantee must be undertaken by an Electrolux Service Force Centre. Any appliance or defective part replaced shall become the Company's property.
This guarantee is in addition to your statutory and other legal rights.
Home visits are made between **8.30am** and **5.30pm** Monday to Friday. Visits may be available outside these hours in which case a **premium** will be charged.

Exclusions

This guarantee does not cover:

- Damage or calls resulting from transportation, improper use or neglect, the replacement of any light bulbs or removable parts of glass or plastic.
- Costs incurred for calls to put right an appliance which is improperly installed or calls to appliances outside the United Kingdom.
- Appliances found to be in use within a commercial environment, plus those which are subject to rental agreements.
- Products of Electrolux manufacture which are NOT marketed by Electrolux.

European guarantee

If you should move to another country within Europe then your guarantee moves with you to your new home subject to the following qualifications:

- The guarantee starts from the date you first purchased your product.
- The guarantee is for the same period and to the same extent for labour and parts as exists in the new country of use for this brand or range of products.
- The guarantee relates to you and cannot be transferred to another user.
- Your new home is within the European Community (EC) or European Free Trade Area.
- The product is installed and used in accordance with our instructions and is only used domestically, i.e. a normal household.
- The product is installed taking into account regulations in your new country.

Before you move please contact your nearest Customer Care Centre, listed below, to give them details of your new home. They will then ensure that the local Service Organisation is aware of your move and able to look after you and your appliances.

France	Senlis	+33 (0)344 62 22 22
Germany	Nurnberg	+49 (0)911 323 2600
Italy	Pordenone	+39 (0)1678 47053
Sweden	Stockholm	+46 (0)20 78 77 50
UK	Slough	+44 (0)1753 219 898

Installation Instructions

⚠ It is dangerous to alter the specifications or attempt to modify this product in any way.

⚠ Care must be taken to ensure that the appliance does not stand on the electrical supply cable.

⚠ Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.

Technical Specifications

DIMENSIONS	Height Width Depth	85 cm (33.5”) 60 cm (23.6”) 60 cm (23.6”)
POWER SUPPLY VOLTAGE TOTAL POWER ABSORBED		230-240 V/50 Hz 2650 W (13A)
MAXIMUM RECOMMENDED LOAD	Cotton, linen Synthetics, delicates	5 kg 2.5 kg
DRUM VOLUME		108 Lts
CONSUMPTIONS	Cotton, linen Cotton, linen	3.9 kWh (5 kg cupboard dry) 3.1 kWh (5 kg iron dry)

CE This appliance complies with the following E.E.C. Directives:
- 73/23 EEC of 19.2.73 (Low Voltage Directive) and subsequent modifications;
- 89/336 EEC of 3.5.89 (Electromagnetic Compatibility Directive) and subsequent modifications.

Positioning

It is recommended that, for your convenience, the dryer is positioned close to your washing machine.

The tumble dryer must be installed in a clean place, where dirt does not build up.

Air must be able to circulate freely all round the appliance. Do not obstruct the front ventilation grille or the air intake grilles in the back of the machine.

To keep vibration and noise to a minimum when the dryer is in use, it should be placed on a firm, level surface.
Once in its permanent operating position, check that the dryer is absolutely level with the aid of a spirit level. If it is not, raise or lower the four adjustable feet until it is.



The feet must never be removed.

Do not restrict the floor clearance through deep-pile carpets, strips of wood or similar. This might cause heat build-up which would interfere with the operation of the appliance.

Important
When operating the tumble dryer, the room temperature must not exceed 35°C, as it may affect the performance of the appliance.

Stacking kit

A special stacking kit is available through your dealer, to enable the mounting of the dryer on top of your washing machine.



Door Reversal Instructions

The appliance is supplied with the door opening from right to left. If you wish to change the opening direction, proceed as follows (see picture A):

1. Unhook door stopper «A» from its seat «a» and loosen from hole «b» by a 90° rotation.
2. Remove the plastic plug from hole «c» by a 90° rotation and re-fix in hole «b».
3. Unscrew hinge «B» (loosen the 2 screws, holding the door securely) and lower the door from the top pivot.
4. Re-insert pin «F» from the door above and below on opposite sides respectively.
5. Loosen door catch «C» by pressing both lugs together (see small illustration).
6. Loosen opposite plastic part «D» as in step 5 (you may need to use a screwdriver to assist in both steps 5 and 6).
7. Interchange and insert parts «C» and «D».
8. Remove screws «E» and refit on the opposite side. Fix hinge «B» on the right handside. Do not fully tighten the screws.



9. To mount door, see picture B:

- First locate into upper right hand hole with upper pin «F».
- Then place lower pin into the hinge «B» at the bottom of the door.
- Align door before tightening hinge.
- Tighten hinge.

10. Remove the plug from hole «d» and refix in hole«a» (Fig. A).
11. Fix door stopper «A» in hole «c» by 90° rotation.
12. Hook door stopper «A» into hole «d».



Electrical connection

Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.

WARNING: THIS APPLIANCE MUST BE EARTHED.

The manufacturer declines any liability should this safety measure not be observed.

Before switching on, make sure the electricity supply voltage is the same as that indicated on the appliance's rating plate. (See picture on page 4).

The appliance is supplied with a 13amp plug fitted. In the event of having to change the fuse in the plug supplied, a 13amp ASTA approved (BS1363A) fuse must be used.
Should the plug need to be replaced for any reason, proceed as described below.
The wires in the mains lead are coloured in accordance with the following code:

Green and Yellow	- Earth
Blue	- Neutral
Brown	- Live



The wire coloured green and yellow must be connected to the terminal marked with the letter «E» or by the earth symbol ⏚ or coloured green and yellow.

The wire coloured blue must be connected to the terminal marked «N» or coloured black.

The wire coloured brown must be connected to the terminal marked «L» or coloured red.
Upon completion there must be no cut, or stray strands of wire present and the cord clamp must be secure over the outer sheath.

WARNING:

A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard.
Ensure that the cut off plug is disposed of safely.

Permanent connection

In the case of permanent connection it is necessary that you install a double pole switch between the appliance and the electricity supply (mains), with a minimum gap of 3mm between the switch contacts and of a type suitable for the required load in compliance with the current electrical regulations.

The switch must not break the yellow and green earth cable at any point.

BENDIX
Electrolux, 55-77High Street, Slough, Berkshire SL1 1DZ

Consumer care telephone number 08705 950950

From the Electrolux Group. *The world's No. 1 choice.*

The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, washing machines, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. USD 14 billion in more than 150 countries around the world.

© Electrolux Household Appliances Limited 2001